


NOTE:

- 1) PACK BEARING CAVITY IN LEAD END ENDBELL WITH POLYREX EM GREASE BEFORE ASSEMBLING THE ROTOR/SHAFT ASSEMBLY.
- 2) PACK BEARING CAVITY IN BEARING CARRIER WITH POLYREX EM GREASE BEFORE ASSEMBLING THE ROTOR AND SHAFT ASSEMBLY. PLACE BUILD STICKER IN CONDUIT BOX.
- 3) ASSEMBLE LEAD END SHAFT SEAL WITH OPEN SIDE (SPRING SIDE) TOWARDS INSIDE OF ENDBELL.
- 4) APPLY A LIGHT COAT OF GREASE ON SHAFT SEAL O-RINGS AT SHAFT END BEFORE ASSEMBLING.
- 5) HAND TIGHTEN CONDUIT BOX COVER TO AVOID DAMAGING TO O-RING.

		TOLERANCES UNLESS SPECIFIED:		 REGAL-BELOIT CORPORATION	DRAWN VV 10/31/09
	DEC	INCHES			CHK
	X	±.1			APPR
	.XX	±.03			SCALE 1:1
	.XXX	±.005			REF
	.XXXX	±.0005		MATL	FMF PR090327
NO	REVISION	BY & DATE	CHK ANG ±1/2°	FINISH	PAGE OF
	THIRD ANGLE PROJECTION		RFP	PREV	SIZE DRAWING NO
			NETWORK FILE NAME		B 040028
					REV